

In the following parts list, assemblies are printed in capital letters. Parts that are included with an assembly are listed and indented directly beneath it. When an assembly is ordered, the assembly and all parts indented beneath it are included in the shipment

When the **USED ON** column lists **A**, the part is used on L07 early models.

When the **USED ON** column lists **B**, the part is used on L07 current models.

ITEM	DESCRIPTION	PART NO.	QTY	USED ON
	<b>L07 LUBRICATOR ASSY, EARLY MODELS</b>	<b>NO NUMBER</b>		<b>A</b>
	<b>L07 LUBRICATOR ASSY, CURRENT MODELS</b>	<b>NO NUMBER</b>		<b>B</b>
1	Plug, fill.....	6205-01	1	A
2	O-ring (service kit item).....	705-01	1	A
3	RED SIGHT FEED DOME ASSY, Plastic (Micro-fog).....	4055-50	1	A
	GREEN SIGHT FEED DOME ASSY, Plastic (Oil-fog, early models only).....	4055-51	1	A
4	● Seal (service kit item).....	4052-89	1	A
5	Body.....	Not normally replaced	1	A
6	O-ring (service kit item).....	2315-24	1	A
7	PLASTIC BOWL ASSY, manual drain.....	3635-63	1	A
8	● Valve, manual drain.....	773-03	1	A
9	● Bowl, plastic.....	Not normally replaced	1	A
10	Plastic bowl, without drain.....	3635-64	1	A
11	METAL BOWL ASSY, manual drain.....	3809-67	1	A
12	● Valve, manual drain.....	773-03	1	A
13	● Bowl, metal.....	Not normally replaced	1	A
14	RED SIGHT FEED DOME ASSY, Plastic (Micro-fog).....	4055-50	1	B
15	● Seal (service kit item).....	4052-89	1	B
16	CARTRIDGE ASSY.....	6206-51	1	B
17	● O-ring (service kit item).....	2305-14	1	B
18	● Cartridge.....	Not available separately-order item 16	1	B
19	● Ball.....	2386-03	1	B
20	● Siphon tube with baffle.....	Not available separately-order item 16	1	B
21	Body.....	Not normally replaced	1	B
22	PLASTIC BOWL ASSY, manual drain.....	3646-54	1	B
23	● O-ring (service kit item).....	2315-23	1	B
24	● Valve, manual drain.....	773-03	1	B
25	● Bowl, plastic.....	Not normally replaced	1	B
26	PLASTIC BOWL ASSY, without drain.....	3635-46R	1	B
27	● O-ring (service kit item).....	2315-23	1	B
28	● Bowl, plastic.....	Not normally replaced	1	B
29	METAL BOWL ASSY, manual drain.....	3647-61	1	B
30	● O-ring (service kit item).....	2315-23	1	B
31	● Valve, manual drain.....	773-03	1	B
32	● Bowl, metal.....	Not normally replaced	1	B

**SERVICE KITS & ACCESSORIES**

Service kit - Includes items circled on exploded view.....	3795-03	AB
Wall mounting bracket.....	5939-08	A
Tamper resistant seal wire.....	2117-01	A
Wall mounting bracket.....	5095-17	B
Wall mounting bracket & plastic panel nut.....	18-025-003	B
Plastic panel nut.....	2962-89	B

\* Bowls (9, 10, 13) and the bowl o-ring (6) can only be used with the early body style (5). The reservoir o-ring fits on the outside diameter of reservoir.

\*\* Bowls and bowl o-rings (23, 25), (27, 28), (30, 32) can only be used with the current body style (21). The reservoir o-ring fits on the inside diameter of reservoir.

