

In the following parts list, assemblies are printed in capital letters. Parts that are included with an assembly are listed and indented directly beneath it. When an assembly is ordered, the assembly and all parts indented beneath it are included in the shipment.

When an assembly lists a letter code in the **ÚSED ON** column, parts that list the same letter code are used in that assembly. Parts coded **A** are used in the Assembly coded **A**, parts coded **B** are used in the Assembly coded **B**, etc

		USED
ITEM DESCRIPTION PART NO.	QTY	ON
1 Body (current models)Not normally replaced	1	
Items 2 thru 18 are not used in this parts list.		
19 PLASTIC BOWL ASSY, manual drain3646-53	1	Α
19 PLASTIC BOWL ASSY, automatic drain *	1	В
20 • Valve, manual drain	1	Α
21 • AUTOMATIC DRAIN ASSY3654-02	1	В
22 • • O-ring, auto drainOrder item 21	1	В
23 • Bowl, plasticNot normally replaced	1	AB
24 • O-ring (service kit item)	1	AB
25 METAL BOWL ASSY, manual drain3647-62	1	С
25 METAL BOWL ASSY, automatic drain *3647-68	1	Ď
26 • Valve, manual drain	1	Ċ
27 • AUTOMATIC DRAIN ASSY3654-02	1	Ď
28 • O-ring, auto drainOrder item 27	1	D
29 • Bowl, metal	1	CD
30 • O-ring (service kit item)	1	CD
31 ELEMENT ASSY665-75	1	
32 O-ring	i	
SERVICE KITS & ACCESSORIES		
Filter element - Includes items circled on exploded view		

- * Automatic drain bowls are not suited for vacuum service.
- ** Current bowls use a lip on the bowl ID to retain bowl o-ring. Early bowls had a lip on the bowl OD and used a larger o-ring. Order o-ring 2315-24 for early bowls.

Wall mounting bracket......5939-06

