



In the following parts list, assemblies are printed in capital letters. Parts that are included with an assembly are listed and indented directly beneath it. When an assembly is ordered, the assembly and all parts indented beneath it are included in the shipment.

ITE	M DESCRIPTION PART NO.	QTY
1	Knob, adjusting4207-89	1
2	Screw	4
3	Bonnet	1
4	Washer, thrust5183-05	1
5	Screw, adjusting4230-50	1
6	PLASTIC BONNET ASSY, T-bar adjustment4205-50	1
7	• T-bar and lock nut	1
8	• • Nut	1
9	• Screw	4
10	BonnetNot available separately	1
11	• Spring rest	1
12	Spring, regulating, 30 psig (2 bar)4232-01	1
	Spring, regulating, 60 psig (4 bar)4232-02	1
	Spring, regulating, 150 psig (10 bar)4232-03	1
13	Diaphragm, Relieving (service kit item)4209-50	1
	Diaphragm, Nonrelieving (service kit item)4209-51	1
14	Plug, pipe, 1/8 PTF (service kit item)2338-08	2
	Plug, pipe, ISO R1/8 (service kit item)2338-99	2
15	Gauge, pressure, 1/8 PTF, 60 psig (4 bar)18-013-211	1
	Gauge, pressure, 1/8 PTF, 150 psig (10 bar)18-013-212	1
	Gauge, pressure, ISO R1/8, 4 bar18-013-990	1
	Gauge, pressure, ISO R1/8, 10 bar18-013-989	1
16	Plug, bottom	1
17	O-ring (service kit item)4273-02	1
18	Cover, bottom	1
19	Spring, valve (service kit item)4239-02	1
20	VALVE ASSY (service kit item)4235-50	1
21	O-ring (service kit item)	1
22	O-ring (service kit item)421-01	1
23	BodyNor normally replaced	1
24	Valve, reverse flow, used only on R72R reverse flow regulators773-06	1

SERVICE KITS & ACCESSORIES

OLIVIOL IVIO & ACCESCOVILES	
Service kit, relieving- includes items circled on exploded view	4381-500
Service kit, nonrelieving- includes items circled on exploded view	4381-501
Kit, pipe plug, 1/8 PTF - item 14, contains two	3723-01
Kit, pipe plug, ISO R1/8 - item 14, contains two	3723-06
Wall mounting bracket kit	4224-50
Panel nut	4248-89
Tamper resistant shroud and seal wire (use only with knob adjustment)	4255-51

