

In the following parts list, assemblies are printed in capital letters. Parts that are included with an assembly are listed and indented directly beneath it. When an assembly is ordered, the assembly and all parts indented beneath it are included in the shipment.

ITEM	DESCRIPTION	PART NO.	QTY
1	Knob, adjusting.....	4407-89	1
2	Screw .....	9PM4-13	4
3	Bonnet .....	4405-89	1
4	Washer, thrust .....	5183-01	1
5	Screw, adjusting .....	5675-51	1
6	BONNET ASSY, T-bar adjustment .....	4405-51	1
7	• T-bar and lock nut.....	584-50	1
8	• Nut.....	575-01	1
9	• Screw .....	9PM4-13	4
10	• Bonnet .....	Not available separately	1
11	• Spring rest .....	5044-89	1
12	Spring, regulating, 60 psig (4 bar).....	4432-01	1
	Spring, regulating, 150 psig (10 bar).....	4432-02	1
	Spring, regulating, 250 psig (17 bar).....	4432-03	1
13	Diaphragm, relieving (service kit item).....	4409-50	1
	Diaphragm, non-relieving (service kit item).....	4409-51	1
14	Plug, pipe, 1/4 PTF (service kit item).....	2891-97	2
	Plug, pipe, 1/4 ISO Rc (service kit item).....	2845-02	2
	Plug, pipe, 1/8 ISO G (service kit item).....	2338-99	2
15	Gauge, pressure, 1/4 PTF, 60 psig (4 bar).....	18-013-208	1
	Gauge, pressure, 1/4 PTF, 160 psig (10 bar).....	18-013-209	1
	Gauge, pressure, 1/4 PTF, 300 psig (17 bar).....	18-013-210	1
	Gauge, pressure, 1/4 ISO Rc, 4 bar.....	18-013-266	1
	Gauge, pressure, 1/4 ISO Rc, 10 bar.....	18-013-260	1
	Gauge, pressure, 1/4 ISO Rc, 17 bar.....	18-013-267	1
	Gauge, pressure, 1/8 ISO G, 4 bar.....	18-013-012	1
	Gauge, pressure, 1/8 ISO G, 10 bar.....	18-013-013	1
	Gauge, pressure, 1/8 ISO G, 17 bar.....	18-013-014	1
16	Valve, reverse flow, used only on R73R reverse flow regulators.....	773-06	1
17	Body .....	Not normally replaced	1
18	Plug, bottom .....	4427-89	1
19	O-ring (service kit item).....	2306-23	1
20	Spring, valve (service kit item).....	4419-01	1
21	VALVE ASSY (service kit item).....	4408-50	1
22	• O-ring (service kit item).....	422-01	1
23	Cover, bottom.....	4436-89	1

### SERVICE KITS & ACCESSORIES

Service kit, relieving- includes items circled on exploded view .....	4381-600
Service kit, non-relieving- includes items circled on exploded view .....	4381-601
Kit, pipe plug, 1/4 PTF - item 14, contains two.....	3724-05
Kit, pipe plug, 1/4 ISO Rc - item 14, contains two.....	3724-09
Kit, pipe plug, 1/8 ISO G - item 14, contains two.....	3723-06
Universal wall mounting bracket kit .....	4424-50
R73 neck wall mounting bracket with panel nut .....	5203-06
R73 neck panel nut .....	5191-88
Tamper resistant cover and seal wire (use only with knob adjustment) .....	4455-51

