

In the following parts list, assemblies are printed in capital letters. Parts that are included with an assembly are listed and indented directly beneath it. When an assembly is ordered, the assembly and all parts indented beneath it are included in the shipment.

ITEM	DESCRIPTION	PART NO.	QTY
1	Panel mounting ring	5988-02	1
2	Adjusting screw	5973-99	1
3	Lock nut	5819-99	1
4	Screws:		
	base and bonnet assembly	5987-97	8
	bowl assembly	5987-98	4
5	Bonnet	5955-96	1
6	Upper spring rest:		
	2, 4 and 7 bar	5965-98	1
7	Spring:		
	2 bar	5962-99	1
	4 bar	5964-99	1
	7 bar	5967-99	1
8	Diaphragm assembly (nitrile and stainless steel):		
	relieving type		
	2 bar	5954-99	1
	4 and 7 bar	74036-52	1
	non-relieving type		
	2 bar	5954-97	1
	4 and 7 bar	5954-96	1
9	Bowl assembly (manual drain)	5980-96	1
Items 10 through 12 are not used in this parts list			
13	Retainer, element	74425-89	1
14	Gasket,	5986-01	2
15	Elements		
	5 µm	5984-01	1
	25 µm	5984-02	1
16	O-ring, bowl (nitrile)	2306-36	1
Items 17 through 21 are not used in this parts list			
22	Body (aluminium)*	Not normally replaced	1
23	O-ring, diaphragm insert (nitrile)	2305-32	1
24	Valve cap	5958-01	1
25	Valve seat	5957-01	1
26	O-ring, valve seat (nitrile)	2820-99	1
27	Valve	5956-89	1
28	Valve spring	5959-02	1
29	Pipe plugs (PTF)	2891-197	2

* Specify inlet and gauge port threads.

SERVICE KIT

Regulator section service kit (for aluminium and stainless steel units)

Relieving type

2 bar - items 4, 8, 27, and 28	R38-100R
7 and 4 bar - items 4, 8, 27, and 28	R38-101R

Non-relieving type

2 bar - items 4, 8, 27, and 28	R38-100NR
7 and 4 bar - items 4, 8, 27, and 28	R38-101NR

Filter section service kit

5 µm element

- items 4, 14, 15 and 16	B38-100A(5)
--------------------------------	-------------

25 µm element

- items 4, 14, 15 and 16	B38-100A(25)
--------------------------------	--------------

